





Actiontec V1000H WPS Enabled Devices

Your TELUS wireless gateway will allow you the option of connecting devices wirelessly, creating your own wireless home network.


For your security, your wireless gateway needs to be configured with a wireless network name (SSID) and a network security key. Please make sure to write this information down, as you will need to select your wireless network name and enter in your network security key every time you want to access your wireless home network.

If you have not changed the wireless settings of the device, you will be able to locate the settings at the bottom of the gateway.

Actiontec V1000H	Default Device Settings
 Tested To Comply With FCC Standards FOR HOME OR OFFICE USE This Product Complies with 47CFR Part 68 and Canadian ICES-003 Contains FCC ID: LNQ802MBN Contains IC: 2496A-802MBN US: LNQDL02BQ1000H IC: 2496A-Q1000H	GUI Access: HTTP://192.168.1.254 Username: admin Password: telus Network Name: TELUS001 Wireless Network Key: 984b895c77 WPS PIN: 91771179
 LISTED I.T.E. E212044 Made in China	H/W Ver: 1A F/W Ver: 31.30L.25
 S/N: CVGA0121300001	 MAC ID: 002688000001

Step 1: Press the **button** on the wireless device you want to connect

Step 2: Press the **WPS button** on the Actiontec V1000H for approx 3 seconds.



Step 3: The WPS button on the Actiontec V1000H will flash yellow/red until connection is made.

-Note: client button must be pressed within 120 seconds of pressing Actiontec V1000H WPS button