

# TELUS TV

remote control coding guide



# your new codes

Your TELUS TV® Universal remote control can be programmed to work with your TV and one additional compatible device such as a DVD player or VCR. If you change or replace your TV or your compatible device, you will need to reprogram your remote control. Please use the codes listed on the following pages. These are the most up-to-date codes and are replacing the 'remote control codes' chart found on page 19 of your TELUS TV Instruction Manual.

You may want to print a copy of this booklet, so you can refer to it in the future. Happy viewing!



---

## brand code list

DEVICE	BRAND NUMBER	BRAND CODES
<b>TV</b>	0	RCA, GE, PROSCAN
	1	Apex
	2	JVC
	3	Magnavox, Philips
	4	Panasonic
	5	Sansui
	6	Sharp
	7	Sony
	8	Symphonic
	9	Toshiba
<b>VCR</b>	0	RCA, GE, PROSCAN
	1	JVC
	2	Magnavox, Philips
	3	Mitsubishi
	4	Orion
	5	Panasonic
	6	Sharp
	7	Sony
	8	Symphonic
	9	Toshiba
<b>DVD</b>	0	RCA, GE, PROSCAN
	1	Apex
	2	JVC
	3	Magnavox, Philips
	4	Panasonic
	5	Pioneer
	6	Samsung
	7	Sharp
	8	Sony
	9	Toshiba

## TV brand codes

BRAND	TV BRAND CODES
Abex	1172
Acer	1043
Admiral	1173, 1191, 1001, 1046, 1095, 1056
Advent	1005, 1062, 1219, 1238
Advertura	1174
Adyson	1067
Aiwa	1036
Akai	1002, 1004, 1047, 1078
Alleron	1046
Alba	1058
American Action	1038
Amstrad	1058
Amtron	1038
Amplivision	1067
Anam National	1038, 1003
AOC	1005, 1004, 1029, 1047
Apex	1236, 1243, 1244
Arcam	1067
Audiovox	1190, 1038
Audiosonic	1058
Baysonic	1038
Benq	1044
Beon	1058
Baur	1058
Belcor	1004, 1029
Bell & Howell	1048, 1001
Binatone	1067
Boots	1067
Bradford	1038
Broksonic	1035, 1191, 1000, 1004, 1239, 1246, 1056, 1078
Brokwood	1004, 1029
Bush	1058
Candle	1004, 1008, 1174, 1016, 1047, 1063
Carnivale	1004, 1047
Carver	1062, 1053, 1061
Carrefour	1057
Cathay	1058
Celebrity	1002
Celera	1243
Centurion	1058
CCE	1058, 1067, 1070, 1082, 1088, 1089, 1093
Changhong	1243
Cineral	1190, 1086
Citizen	1105, 1004, 1008, 1038, 1171, 1174, 1177, 1191, 1016, 1047, 1063
Clarion	1038
Clarivox	1058
Colortyme	1004
CME	1058, 1067
Concerto	1004, 1016

## TV brand codes

BRAND	TV BRAND CODES
Contec/Cony	1038, 1012, 1013
Craig	1038
Crosley	1062, 1000, 1053, 1082
Crown	1038, 1062, 1171, 1058
Curtis Mathes	1105, 1000, 1062, 1048, 1190, 1173, 1004, 1015, 1171, 1016, 1047, 1053, 1055, 1078
CXC	1038
Daewoo	1005, 1190, 1004, 1017, 1171, 1014, 1029, 1058, 1078, 1086, 1088
Daytron	1004, 1171, 1029, 1083
Dansai	1058
Denon	1055
Decca	1058
Dixi	1058
Dimensia	1000
Dumont	1004, 1151, 1029
Dual Tec	1067
Durabrand	1004, 1038
Dynatech	1004, 1067
Electroband	1002
Electrohome	1000, 1002, 1003, 1004, 1019, 1022
Emerson	1048, 1035, 1191, 1038, 1004, 1012, 1026, 1030, 1033, 1046, 1123, 1171, 1177, 1179, 1029, 1056, 1078, 1083
Envision	1004, 1047
Erres	1058
Elin	1058
Ferguson	1058
Finlux	1058
Firstline	1067
Fisher	1051, 1048, 1180, 1045, 1067
Fujitsu	1046, 1031
Funai	1038, 1046, 1189
Futuretech	1038
Formenti	1058
Gateway	1245, 1040
GEC	1058
GE	1000, 1054, 1190, 1004, 1003, 1022, 1052, 1087, 1100, 1165, 1203, 1009, 1078
Gibraltar	1004, 1151, 1029, 1047
Goldstar	1004, 1005, 1012, 1019, 1155, 1156, 1171, 1172, 1016, 1029, 1047, 1058, 1067, 1078, 1083
Goodmans	1058, 1067
Granada	1058, 1067
Gradiente	1242, 1016, 1049, 1061, 1071, 1081, 1084, 1090, 1091, 1094
Grunpy	1038
Grundy	1038, 1046, 1171, 1058
Hanseatic	1058
Hallmark	1004
Harman Kardon	1062, 1053

## TV brand codes

BRAND	TV BRAND CODES
Harvard	1038
Havermy	1173
Hello Kitty	1190
Hinari	1058
Hisense	1237
Hitachi	1004, 1012, 1013, 1032, 1059, 1060, 1136, 1145, 1148, 1179, 1016, 1055, 1067, 1078, 1083, 1085
Hypsyn	1058
IMA	1038
ICE	1067
Indiana	1058
Innova	1058
Infinity	1062, 1053
Intervision	1058, 1067
Interfunk	1058
Inteq	1151
IC Penny	1078
Janeil	1174
JBL	1062, 1053
JCB	1002
JC Penney	1105, 1000, 1236, 1004, 1005, 1054, 1072, 1013, 1022, 1008, 1052, 1087, 1100, 1104, 1109, 1171, 1172, 1203
Jensen	1004
JVC	1159, 1054, 1191, 1242, 1012, 1013, 1027, 1060, 1065, 1066, 1123, 1049, 1084
Kawasho	1002, 1004
Kaisui	1067
KEC	1038
Kenwood	1004, 1019, 1029, 1047
Kendo	1058
KLH	1236, 1243, 1244
Kloss Novabeam	1038, 1068, 1069, 1174, 1074
KTV	1038, 1004, 1171, 1177, 1047, 1067, 1078, 1083
Korpel	1058
Kornig	1058
Liesenk & Tter	1058
Leyco	1058
LG	1005, 1016, 1078, 1083
Loewe	1062
Logik	1001
Luxman	1004, 1016
LXI	1062, 1000, 1072, 1048, 1236, 1004, 1100, 1109, 1203, 1053, 1078, 1082
Magnavox	1062, 1004, 1008, 1075, 1219, 1000, 1019, 1068, 1069, 1076, 1133, 1047, 1053, 1063, 1064, 1073, 1074, 1077, 1078, 1082, 1083
Majestic	1001
Manesta	1067
Matsui	1058, 1067
Marantz	1062, 1004, 1059, 1047, 1053, 1058

## TV brand codes

BRAND	TV BRAND CODES
Mark	1058
Matsushita	1170
M-Electronic	1058, 1067
Mediator	1058
Megatron	1004, 1059, 1055
Memorex	1048, 1170, 1191, 1004, 1001, 1005, 1046, 1023, 1016, 1056
MGA	1005, 1051, 1004, 1019, 1022, 1079, 1080, 1029, 1047, 1078
Midland	1054, 1000, 1151, 1100, 1171, 1172
Minutz	1052
Mitsubishi	1005, 1051, 1173, 1170, 1004, 1019, 1022, 1034, 1079, 1080, 1125, 1029, 1078
Montgomery Ward	1001
Motorola	1173, 1003
MTC	1105, 1005, 1004, 1016, 1029, 1047
Multitech	1038, 1067
NAD	1072, 1236, 1004, 1006, 1109, 1136
NET-TV	1042
NEI	1058
NEC	1005, 1004, 1003, 1016, 1029, 1047, 1061, 1078
Neckermann	1058
Netsat	1058
Nikko	1004, 1047
Nikkai	1058
Otto Versand	1058, 1067
Onwa	1038
Optimus	1048, 1170, 1136
Optonica	1173, 1095
Orion	1035, 1191, 1030, 1024, 1056, 1058
Osaki	1067
Panama	1067
Panasonic	1062, 1054, 1170, 1003, 1011, 1109, 1248
Penney	1016, 1029, 1047
Philco	1062, 1004, 1005, 1191, 1003, 1008, 1012, 1019, 1068, 1069, 1075, 1029, 1047, 1053, 1055, 1056, 1063, 1064, 1073, 1074, 1077, 1078, 1082, 1083, 1085, 1086, 1092
Philips	1062, 1002, 1003, 1004, 1008, 1012, 1019, 1068, 1069, 1075, 1076, 1087, 1219, 1018, 1053, 1058, 1073, 1074, 1077, 1082
Phonola	1058
Pilot	1004, 1171, 1029, 1047
Pioneer	1004, 1136, 1179, 1037
Portland	1005, 1004, 1171, 1029, 1078
Price Club	1105
Prima	1238
Prism	1054
Proscan	1000, 1009, 1100, 1203, 1078, 1081
Protech	1058, 1067

## TV brand codes

BRAND	TV BRAND CODES
Proton	1004, 1012
Pulsar	1151, 1029
Pulser	1004
Quelle	1058
Quasar	1054, 1170, 1003, 1109, 1041
Radio Shack	1000, 1038, 1004, 1048, 1016, 1029, 1047
Radiola	1058
Radio Shack/Realistic	1000, 1038, 1004, 1012, 1048, 1095, 1171, 1172
RCA	1100, 1000, 1005, 1003, 1004, 1009, 1019, 1054, 1096, 1098, 1099, 1101, 1102, 1103, 1129, 1179, 1188, 1190, 1203, 1240, 1252, 1029, 1078, 1081, 1253
Revox	1058
RTF	1058
R-Line	1058
Runco	1004, 1151, 1047
Realistic	1016, 1029, 1047
Sampo	1004, 1171, 1172, 1245, 1047
Samsung	1105, 1005, 1004, 1012, 1013, 1015, 1017, 1019, 1020, 1104, 1106, 1171, 1172, 1016, 1029, 1047, 1058, 1067, 1070, 1078, 1083
Sansei	1190
Sansui	1191, 1247, 1056
Sanyo	1048, 1004, 1080, 1169, 1180
SBR	1058
Scimitsu	1029
Schneider	1058
Scotch	1004
Scott	1035, 1038, 1004, 1012, 1046, 1029
Sears	1000, 1051, 1048, 1072, 1109, 1062, 1236, 1004, 1013, 1019, 1046, 1066, 1100, 1110, 1180, 1189, 1203, 1016, 1053, 1078, 1082
SEG	1067
Semivox	1038
Semp Toshiba	1236
Sharp	1173, 1004, 1010, 1012, 1026, 1095, 1112, 1171, 1083
Sheng Chia	1173
Shogun	1004, 1029
Signature	1001, 1173
Simpson	1008, 1063, 1064
Siemens	1058
Sony	1002, 1218, 1007, 1039
Soundesign	1038, 1004, 1008, 1046, 1063
Soundwave	1058
Sontec	1058
Sonoko	1058
Sky	1058
Squareview	1189
SSS	1004, 1038, 1029

## TV brand codes

BRAND	TV BRAND CODES
Starlite	1038
Standard	1067
Supre-Macy	1174
Supreme	1002
Sylvania	1062, 1004, 1008, 1019, 1068, 1069, 1075, 1076, 1189, 1251, 1028, 1047, 1053, 1063, 1064, 1073, 1074, 1077, 1078, 1082
Symphonic	1038, 1026, 1025, 1033, 1046, 1155, 1189
Sysline	1058
Tandy	1173, 1067
Tashiko	1072, 1067
Tatung	1003, 1058, 1067
Tec	1067
Technics	1054, 1170
Techwood	1054, 1004, 1016
Teknika	1105, 1005, 1062, 1038, 1001, 1004, 1008, 1012, 1013, 1046, 1076, 1170, 1171, 1016, 1029, 1053, 1063
Telefunken	1016
Teleton	1063, 1067
Tera	1004, 1012
Thorn	1058
TMK	1004, 1016
TNCi	1151
Toshiba	1105, 1072, 1109, 1048, 1236, 1170, 1000, 1118, 1190, 1241
Totevision	1171
TVS	1191
Universum	1058
Universal	1052, 1087
Vector Research	1004, 1047
Vestel	1058
Visa	1058
Victor	1242, 1066, 1049
Vidikron	1062, 1053
Vidtech	1004, 1005, 1029, 1078, 1085
Video Technic	1067
ViewSonic	1245, 1050
Viking	1174
Wards	1062, 1000, 1005, 1004, 1001, 1019, 1033, 1046, 1052, 1068, 1069, 1075, 1076, 1087, 1095, 1173, 1016, 1029, 1047, 1053, 1064, 1073, 1077, 1078, 1083
Watson	1058
Waycon	1236
Waltham	1067
White Westinghouse	1191, 1000, 1001, 1190, 1056, 1058
Yamaha	1005, 1004, 1019, 1029, 1047
Yoko	1058, 1067
Zenith	1051, 1151, 1191, 1004, 1000, 1001, 1021, 1152, 1056

## VCR brand codes

BRAND	VCR BRAND CODES
Admiral	2001, 2020
Adventura	2026, 2005
Aiko	2027, 2028
Aiwa	2026, 2005, 2040
Akai	2003, 2111, 2112, 2119
American Action	2028
American High	2021, 2007
Asha	2013,
Audio Dynamics	2009, 2010
Audiovox	2014
Beaumark	2013
Bell & Howell	2011
Broksonic	2012, 2025, 2031, 2146, 2147, 2020, 2030, 2037
Calix	2014
Candle	2013, 2014, 2015, 2016, 2017, 2018
Canon	2021, 2022, 2007, 2034, 2035
Capehart	2110
Carver	2062
CCE	2027, 2061, 2008, 2028, 2036, 2042
Citizen	2013, 2014, 2015, 2016, 2017, 2018, 2019, 2027, 2028
Cineral	2028, 2042
Colortyme	2009
Colt	2061, 2008
Craig	2013, 2014, 2023, 2061, 2008, 2036
Curtis Mathes	2000, 2009, 2013, 2016, 2018, 2021, 2022, 2024, 2087, 2007, 2035, 2040
Cybernex	2013
Daewoo	2015, 2017, 2019, 2025, 2026, 2027, 2110, 2141, 2028, 2035, 2042
Daytron	2061, 2110
DBX	2009, 2010
Dimensia	2000
Dynatech	2026, 2005
Electrohome	2014, 2029
Electroponic	2014
Elbe	2045
Emerson	2003, 2012, 2014, 2015, 2021, 2024, 2025, 2026, 2029, 2031, 2032, 2033, 2038, 2041, 2065, 2116, 2130, 2142, 2148, 2005, 2020, 2028, 2030, 2037, 2040, 2042
Fisher	2011, 2023, 2049, 2051
Fuji	2021, 2119, 2007
Funai	2026, 2002, 2005, 2040
Garrard	2026, 2005
GE	2000, 2013, 2021, 2022, 2053, 2087, 2089, 2120, 2007, 2035
Go Video	2131, 2138
Goldstar	2009, 2014, 2018, 2057, 2045
Gradiente	2026, 2005, 2006, 2039, 2040, 2043, 2044
Harley Davidson	2026, 2005

## VCR brand codes

BRAND	VCR BRAND CODES
Harman Kardon	2009, 2045
Harwood	2061, 2008
Headquarter	2011
Hitachi	2026, 2055, 2056, 2057, 2107, 2111, 2120, 2005, 2034
Hi-Q	2023
IC Penney	2035
Instant Replay	2021, 2034, 2035
JCL	2021
JC Penney	2009, 2010, 2011, 2012, 2013, 2014, 2021, 2022, 2051, 2055, 2056, 2061, 2062, 2107
Jensen	2055, 2056, 2111
JVC	2009, 2010, 2011, 2018, 2111, 2123, 2132, 2006, 2043
KEC	2028
Kenwood	2009, 2010, 2011, 2016, 2018, 2111, 2123, 2045
KLH	2061, 2008
Kodak	2014, 2021, 2007
LG	2014
Lloyd	2026, 2005
Logik	2061, 2008
LXI	2014, 2040
Magnasonic	2028
Magnavox	2021, 2022, 2062, 2063, 2104, 2124, 2005, 2007, 2034, 2035
Magnin	2013
Marantz	2009, 2010, 2011, 2016, 2018, 2021, 2022, 2062, 2007, 2045
Marta	2014
Matsushita	2021, 2007
MEI	2021, 2007
Memorex	2001, 2011, 2013, 2014, 2021, 2022, 2023, 2026, 2031, 2104, 2130, 2005, 2007, 2020, 2030, 2035
MGA	2029, 2065
MGN Tech.	2013
Midland	2053
Minolta	2055, 2056, 2107
Mitsubishi	2029, 2055, 2056, 2065, 2066, 2123
Montgomery Ward	2001
Motorola	2001, 2021, 2007
MTC	2013, 2026, 2005
Multitech	2013, 2016, 2026, 2053, 2061, 2005, 2008, 2040
M-Electronic	2045
NEC	2009, 2010, 2011, 2018, 2111, 2123, 2045
Nikko	2014
Nokia	2042
Noblex	2013
Olympic	2034, 2035
Olympus	2021, 2007
Optimus	2001, 2014

## VCR brand codes

BRAND	VCR BRAND CODES
Optonica	2096
Orion	2000, 2031, 2130, 2004, 2020, 2030
Panasonic	2021, 2022, 2109, 2125, 2127, 2143, 2151, 2152, 2007, 2034, 2035
Pentax	2016, 2055, 2056, 2107, 2120
Pentax Research	2018
Penny	2007, 2045
Philco	2021, 2022, 2062, 2063, 2007, 2020, 2030, 2034, 2035, 2037, 2042, 2045
Philips	2021, 2022, 2062, 2096, 2124, 2136, 2155, 2007, 2034, 2035
Pilot	2014
Pioneer	2010, 2055, 2123, 2034
Polaroid	2144
Portland	2016, 2017, 2019, 2110
Proscan	2000, 2034, 2035
Protec	2061, 2008
Pulsar	2104
Quarter	2011
Quartz	2011
Quasar	2021, 2022, 2109, 2125, 2007, 2034, 2035
Radio Shack	2001, 2014, 2096, 2005
Radio Shack/Realistic	2011, 2013, 2014, 2021, 2022, 2023, 2026, 2029, 2049, 2096
Radix	2014
Randex	2014
RCA	2000, 2003, 2013, 2021, 2022, 2055, 2056, 2082, 2083, 2085, 2086, 2087, 2088, 2089, 2100, 2107, 2120, 2125, 2133, 2007, 2034, 2035, 2157
Realistic	2001, 2011, 2013, 2014, 2015, 2021, 2022, 2023, 2026, 2029, 2049, 2096, 2005, 2007, 2035, 2040
Ricoh	2128
Runco	2104
Samsung	2013, 2015, 2033, 2053, 2055, 2112, 2134, 2149, 2156
Sanky	2001, 2104
Sansui	2010, 2031, 2111, 2123, 2130, 2005, 2020, 2030
Sanyo	2011, 2013, 2023, 2135, 2042
Scott	2012, 2015, 2025, 2032, 2038, 2065, 2116
Sears	2000, 2011, 2014, 2021, 2023, 2026, 2049, 2051, 2055, 2056, 2107, 2005, 2007, 2040
Sharp	2001, 2017, 2029, 2096
Shintom	2056, 2061, 2098, 2119, 2008, 2036
Shogun	2013
Signature	2001, 2040
Singer	2021, 2061, 2128, 2008, 2036
Sony	2098, 2099, 2119, 2150, 2005, 2007
STS	2021, 2107
Sylvania	2021, 2022, 2026, 2062, 2063, 2065, 2124, 2142, 2154, 2005, 2007, 2034, 2035, 2040

## VCR brand codes

BRAND	VCR BRAND CODES
Symphonic	2026, 2005, 2040
Tandy	2011
Tashiko	2014
Tatung	2111
Teac	2026, 2085, 2111, 2005, 2040
Technics	2021, 2007
Teknika	2014, 2021, 2022, 2026, 2100, 2005, 2007
Thomas	2005
Toshiba	2015, 2049, 2051, 2055, 2065, 2116
Totevision	2013, 2014
TMK	2013, 2024
Unitech	2013
Vector Research	2009, 2010, 2015, 2016, 2045
Victor	2010
Video Concepts	2009, 2010, 2015, 2016
Videosonic	2013
Wards	2001, 2013, 2014, 2015, 2021, 2022, 2023, 2026, 2029, 2055, 2056, 2061, 2088, 2096, 2107, 2116, 2005, 2007, 2008
White Westinghouse	2008, 2020, 2028
XR-1000	2021, 2026, 2061, 2005, 2007, 2008
Yamaha	2009, 2010, 2011, 2018, 2111, 2045
Zenith	2026, 2098, 2104, 2119, 2128, 2130, 2137, 2145, 2005, 2020, 2030

## DVD brand codes

BRAND	DVD BRAND CODES
Aiwa	3465
Apex	3383, 3384, 3430, 3456
Audiovox	3466
Blaupunkt	3470
Bose	3464
Broksonic	3379, 3402
Clarion	3432
Classic	3433
Cyberhome	3414
Daewoo	3390, 3471
Denon	3467, 3487, 3488
Emerson	3386, 3387, 3391, 3392, 3403
Fisher	3468
Funai	3387, 3457
GE	3410, 3445, 3451, 3485
Go Video	3372, 3463, 3495
GPX	3446
Gradiente	3141
Harman Kardon	3459
Hitachi	3458, 3460
Irradio	3484
JVC	3146, 3422, 3428, 3429, 3447
Kenwood	3142, 3489, 3492
Konka	3353, 3354
Koss	3411
Lasonic	3412
Magnavox	3143, 3162, 3357, 3358, 3421
Marantz	3477
Memorex	3479
Mintek	3145
Mitsubishi	3481, 3483, 3496
Nakamichi	3448
NAD	3386, 3473
Nexxtech	3493
Norcent	3450
Onkyo	3474, 3478
Oritron	3152, 3141
Panasonic	3148, 3394, 3395, 3407, 3437, 3443
Philips	3162, 3357, 3358, 3371, 3377, 3423, 3424, 3441
Pioneer	3149, 3165, 3397, 3427, 3436
Polariod	3398
Proscan	3160, 3451, 3491
Qwestar	3152
RCA	3153, 3160, 3374, 3380, 3382, 3408, 3415, 3425, 3439, 3451, 3497
Samsung	3154, 3404, 3418, 3434, 3449
Sansui	3168, 3401
Sampo	3452
Sanyo	3376, 3453
Sharp	3369, 3431

## DVD brand codes

BRAND	DVD BRAND CODES
Sherwood	3454
Sony	3157, 3159, 3164, 3166, 3360, 3361, 3405, 3419, 3440
Sylvania	3387, 3391, 3409, 3469
Techwood	3475
Toshiba	3162, 3365, 3366, 3381, 3420
Xbox	3160
Yamaha	3490
Zenith	3378, 3400, 3486

## PVR brand codes

BRAND	PVR BRAND CODES
RePlay	2140
Tivo	2139

## combo brand codes

DEVICE	BRAND	TV BRAND CODES	VCR BRAND CODES	DVD BRAND CODES
TV / VCR COMBO	Broksonic	1246	2146	
	Daewoo	1190	2027	
	RCA	1000	2000	
	Gradiente	1094	2039	
TV / DVD COMBO	Broksonic	1239		3379
	RCA	1000, 1252		3160, 3415
	Sansui	1247		3401
	Toshiba	1241		3381
TV / DVD / VCR COMBO	Panasonic	1248	2152	3406, 3407
	RCA	1000	2000	3160, 3408
	Sylvania	1251	2154	3409
TV / DVD / VCR COMBO	Broksonic		2147	3402
	Daewoo		2141	3390
	Emerson		2142, 2148	3391, 3403
	Go Video		2131	3372
	JVC		2132	3373
	Panasonic		2143	3395
	Philips		2136	3357
	Polaroid		2144	3398
	RCA		2133	3374
	Samsung		2134, 2149	3375, 3404
	Sanyo		2135	3376
	Sony		2150	3405
	Sylvania		2142	3391
	Zenith		2137, 2145	3378, 3400
PORTABLE DVD	RCA			3382
	Sharp			3413
	Toshiba			3494